



# MINIDABONE

## FIRMWARE UPGRADE INSTRUCTIONS

Firmware upgrades are a quick and easy way to add the latest functionality to your **MINIDAB**. Here is your step-by-step guide to updating your **MINIDAB** with a firmware upgrade.

The first part of the process is to download the firmware from the Oono website. This can be found in the **MINIDAB** Support Centre section. Click on the link for the firmware you require and save it to your computer when prompted.

Before you begin a firmware upgrade you should ensure that:

- the **MINIDAB** is charged (at least 50%)
- you can access the **MINIDAB**'s internal memory
- you have enough space in the **MINIDAB**'s internal memory



1. Connect your **MINIDAB** to your computer using the USB cable provided.



2. Find the firmware file (.YUF) on your computer and copy it into the **MINIDAB**'s internal memory drive.



(When you connect your **MINIDAB** two new drives should appear, the one that comes first alphabetically is the internal memory.)

3. Once the file has been copied successfully, disconnect the **MINIDAB** from the computer.
4. Once disconnected, the **MINIDAB** will automatically start the firmware upgrade.
5. Once it's complete you will be asked to reset **MINIDAB**. The reset button can be found on the right hand side of the **MINIDAB** under the volume and hold buttons. Access the button by pushing something thin into the hole.
6. Your **MINIDAB** is now updated and you can now access the improved functionality.

If you have any problems with your firmware upgrade please contact a member of our Support Team at [support@oono.co.uk](mailto:support@oono.co.uk).